

SPAREZONESA
& EV TECH



Email: info@sparezonesa.com
Web: www.sparezonesa.com



专注国产自主品牌汽车配件
Focus on domestic brand auto parts





离合器三通接头1701722001-B11

组合开关3774010-02

导轨1006700003-B11F

排气管垫1118103003-B11F

离合器分泵1701715001-B11



排气管管1008201003-B11F

链条MN128497

组合开关3774010007-B11F

油浮子1106013A02

张紧轮SMW252062



离合器1600011002-B11

升降器开关3746010003-B11F

节气门MW251078

下摆臂2904100-A01

缸垫1003400003-B11F



刹车总泵3540210-02

变速箱1500010001-B11A

离合器总泵1608010001-B11

后分泵3502110001-A02

燃油泵1101102BA-A01



大修包MW300358

传感器3611010001-A02

出气管1119020003-B11

后托臂2914060001-B11

发动机1000200003-B11F



缸盖总成1003500003-B11F-1T

全车锁芯3704010-A01C

机油格SMD360935

日行灯4137010001-B11F

变速箱壳体BXFT6AT



涡轮增压器1118110003-B11F

横拉杆3411710-02

气门室盖1035A872-A01

倒车镜8202010-A01

叶子板8403011001-B11



三元催化器1205020012-B11

轴承3103110-A01

方向机3401010002-B11F

雾灯4116010-A01

升降器6104010001-B17



机油泵4G20T-1003003-01

换挡线1504200CA-A01

钢圈3113101002-B17

叶子板内衬5512010-A01

发电机1800A211



空气格1109101BA-A01

机脚胶1001410-A01

马达3708011001-B11

车门6101010001-B11

喷水壶5207012AB-A01



中网8401100-A01

大灯4121010001-B11F-A1

刹车盘3501102-A01

换挡机构1504130CA-A01

倒车雷达3603020AB-A01



刹车片3502111001-A02

前桥2810100-A01

水泵1307100003-B11F

门锁6105030-A01

VVT1008011-04



B11-2919030/40三角臂后



T11-3772010AD/20AD前大灯-电动



B11-3600020风扇继电器



B11-1602070离合器分泵



480-101 1030机油泵



11-1504310换挡线AT



T11-1205210BA-三元催化主



A21-5205021雨刮电机



T11-8112010ND空调控制面板



QR512-1602101分离轴承



A11-37071 10BA火花塞



4G15-SGXLB时规修理包11件套



Q22-2906020连接器-前



A15-8202010/20倒车锁



A15-371 7050BC牌照灯护板



480-1007050张紧轮



T11-3732030BA/40BA后雾灯



A13-610501 0车门中控锁



A15-8201010至内镜



S11-35050T0刹车总泵



A21-3505010A刹车总泵



T11-3773010BA/20BA后灯



480-1007050BA 张紧轮新



H13-3505010 刹车总泵



477F-1004020活塞-STD



T11-3774110转向开关



S11-3501080前刹车片



480-1 007081-正时带97MR.22



A113701315BA空调/电机带6PK1268



B11-3402080螺旋电缆



A15-1608010离合器总泵



M11-3501080前刹车片



A11-6BH3501080前刹车片



A21-6105010中控锁



519MHA-1602501分离轴承座压



372-1012010机油格



473H-1007073正时带167YU25



A21-2203030外球笼



S11-3402080螺旋电缆



481H-1 007073BA正时带173YU25



481H-1004020活塞-STD



A11-8111200AB张紧器-新



S11-3001017前轮芯



S11-3774110转向开关



M11-1001110悬架软垫



T11-350010AB真空泵总成



S11-6102510BA扶手盖



L513EHA-1707019油泵滤油器



T11-372301 0BA前舱电器盒



B21-3541110-真空厚总成电子



E4G16-3811091偏心轴电磁阀



D4G15B-1307010水泵



D4G15B-1 006060偏心轴相位器



S11-3301030后轮轴承总成



A21-3704010点火开关坐



A21-3723010前舱电器盒



S12-1 703540换挡手柄球



QR512E-1 707013背能器



D4G15-13061 1 0节温器-电子-带座



030机油泵



1011100-EG01机油泵



6101200-J08车前门



6201200-J08车后门



2804101XJ08XA后保险杠



1017100-EG01机油格



3701100-J08发电机



1004016-EG01透镜



3707100-EG01火花塞



2904110-G08下摆臂



2203100-G08传动轴总成




B403101-J08叶子板



2905101-G08前减震角



3411120-S08外球头



2915110-J08后减震总成



3411120-G08方向机



3502100-G08后分泵




1117100-V08汽油格



1601100-EG01离合器盘



1601200-EG01离合器片



4134400XG08A刹车灯开关AT




1608100-S08离合器总泵



8104400CJA08空调格




3708100-EG01起动机



3501140-G08前刹车片



3103101-G08前轮芯



2906200-G08前稳定杆球头



1001100-G08机脚胶L



3502340-G08刹车后片



8402100-J08机盖



1001300-G08机架胶后MT




5207120XS56XA喷水泵



1001200-G08机架胶R



3765100-EG01节气门总成



6104300-J08升降器前



3501011-G08前碟



6105000-J08前门锁



2810000-G08前桥



8105100A-G08冷凝器



3540230-G08刹车总泵



4134400-S08A刹车灯开关MT



102110-EG01VVT相位器



4121100-J08大灯



1609010-001A离合分泵



2803101-J08前保险杠



41161000-J08前雾灯



1307100-EG01水泵



4116300-J08尾灯内



1123100-G08汽油泵



3774200-J08组合开关



3705100-EG01点火线圈



B202100-J08倒车镜




1308100S16电子扇



1109101-S16空气格



1301100-S16水箱



2905200-J08前减震




4133100XJ08XB尾灯外



3540240-G08真空助力器总成



3611100-EG01氧传感器



2803104-J08雾灯框



3408100-S08转向油泵





后轮轴承3502180-W01 气门室盖1003020-B05 氧传感器3781010-A01 涡轮增压器1118010-A01 离合器总泵1608100-U01



机脚1001070-B04 前大灯37720120-M01 MINI主开关A101096-0202 后分泵3508511-M01 压缩机8104100-U01



1.5T机油散热器1013010-B01 CS35半轴2201010-W03 478相位齿轮3550050-W01 ABS传感器 时规套6590186100



蒸发器8100110-W06 478凸机H15000-0001 CS35副车架8202010-W04 478链条H15007-1400 478正时张紧器



478正时H155007-1500 EADO下护板5504211-BN01 478机油泵链条张紧器 主气滤3504230-W01 刹车灯开关3504230-W01



CS35升降器 室内机8201010-H01 CS35前桥2810100-W01 减震器顶胶 3505110-W02



478相位齿轮1006030-B01 1.5T/476发电机3701010-B08 CS35叶子板8403122-W01 478波箱滤网H16023-5240 电子节气门



CS75 plus尾灯3773021-0D01 478缸盖总成1003010-B01 CS15空滤壳1109100-B001 发电机套1000050-B01 天语SX4机脚11610-56K00



478正时链条H15007-1400 CS35喷水总成5027100-W01 CS35水箱AT1301000-02 478油泵1011010-B01 1.5T电子节气门13306010-B09



CS35离合器套621310408 CS35机脚1001060-B05 CS15右机脚1001770-H10 奔奔MINI方向机3401100-K02 奔奔MINI备水缸1311010-K01



CS35下摆臂2904300-W01 凸轮轴位置传感器F01R00B01B CS35升降器开关3746050-W01 SX4油门踏板49400-56K50 1.5T涡轮增压器1118100-B15



CS35电喷外拉手6105530-W01 备水壶1311100-BH01 478缸垫1003040-B01 CS15发电机皮带轮1025060-H01 CS35上中网803120-W01



1.前杠本体2803101U7300



2.前拖钩盖板2803105U7300



3.牌照板2803106U7300



4.前杠下格挡饰板2803102U7300



5.前格栅总成2803200U7300



6.前保险杠固定支架2803710U7300



7.前雾灯盖板2803103U7300



8.前保险杠亮饰条2803150U7300



9.前组合灯4121100U7300



10.前防撞梁总成2803400U7300



11.前副车架总成2803500U7300



12.小副车架2803620U7312



13.散热器总成1301100U3460



14.散热器风扇总成1308100V5070



15.冷凝器8105100U7300



16.付水壶1311100U7300



17.左前驱动轴总成2200300U7310



18.右前驱动轴总成2200400U7310



19.下摆臂2804100U7300



20.前减震器2905110U7300



21.前连接杆球头2906200U7300



22.方向机3401100U7300



23.方向机外球头3401100U7300-F01




24.方向机内球头3401100U7300-F02




25.前刹车片3503100U7300-F01



26.后刹车片3504100U7300-F031



27.前刹车盘3503300U7300



28.后刹车盘3504300U7300



29.前刹车软管3506100U7300



30.后刹车软管3506300U7300



31.喷水泵5207100U7300



32.后杠组件2804100U7300-F011



33.后防撞梁2804400U7300



34.后拖钩盖板2804103U7300



35.后尾灯外4133100U7300



36.后尾灯内4133300U7300



37.后雾灯4133500U7300



38.雾灯电烙条2804105U7300



39.后悬架总成1001600U7300



40.右悬架总成1001800U7310



41.空滤总成1109100U7300



42.发动机下护板2802100U7300



43.元宝梁2810100U7300



44.后副车架总成45.后减震器2820100U7300



45.后减震器2811300U7300



46.后稳定杆球头2916200U7300



47.后横向稳定杆2916110U7300



48.纵臂总成2921110U7300



49.前下拉杆总成2922100U7300



50.后横臂总成2923100U7300



51.上拉杆总成2924100U7300



52.后轮单元3104120U7300



53.前轮轴承3103100U2011



54.后减震器2915100U7300



55.前横向稳定杆2906110U7300




56.前转向节3001101U7300



57.后转向节总成3104110U7300



58.前横向稳定杆衬套2906202U7300



59.后横向稳定杆衬套2916140U7300



60.前保险杠上盖板2803252U7300



东风风光
东风风神



S4121100 Front head lamp 大灯



S8202100 Wing mirror 倒车镜



S6104100 Window lifter 升降器



S1001110 suspension component 机脚胶



Sa35400 Brake pump 刹车总泵



B1301100 Radiator assy. 水箱



S2914300 Lower arm, left/right 后悬控制臂



7481003 Front head lamp 大灯



B4133400 Right tail lamp 尾灯



B8202100 wing mirror 倒车镜



B4116100 Front fog lamp 前雾灯



B377410D1 Lamp combination switch 组合开关



B1301100 Radiator assy. 水箱



B3674100C1 BCM remote key 防盗控制



B1308000 Cooling fan assy. 水箱电子扇



A484121100 Front head lamp 大灯




A8202100 wing mirror 倒车镜



F5306310B25 Center vent, air distribution 仪表台出风口



L8101100 暖风水箱



57230009Z Outer handle door 外拉手



LBA1132100 Throttle assy 节气门



04663904AA Valve oil seal BMW machine 气门油封宝马机



S6105110 Lock door 门锁



7521001 Right tail lamp 尾灯



L1123100 Fuel pump 电子燃油泵总成



7481003 Front head lamp 大灯



6121008AA Front grille 中网



2462700 Air filter assy. 空气滤



3385000AP 换挡杆球头



LF48103-3802100C Contactless speed sensor 车速传感器

东风风光



1600200-F00-03 水泵 580



1301110-FK01 水箱 580



1003700E0100 缸垫 580



3550135-SA01 轮速传感器



3774080-FK02 刹车灯开关



1101 600-FA01 水箱 580



3746100-SA01 刹车防夹控制器 A



2803011-FK01 前保险杠 580



1021800-D03-00 机油控制阀 580



1010100K0000 机油泵 580



2810110-SA01 前保险杠 580



411 6010-FK01 前雾灯



1600100-F00-03 水泵 580



1706265-MF515A01 高压分泵 580



2803011-FA01 前保险杠 580



3502450-FB01 后分泵



2401010-SA01 后保险杠 580



6309010-FA01 背门铰链杆



2915100-FK01 后减震



5504011-FK01 叶子板内衬



8403111-FA01 叶子板



3501610-SA01 前轮芯



1101680-SA01 油精加油铁嘴 580



3202200-FS01 倒车镜



2904100-FK01 前减震器总成 580



3501470-FB01 后分泵



1308100-FK01 水箱电子扇 580



3501101-SA01 前碟



1307100-K00-00 水泵 580



3778010-SA01 电子转向轴锁



东风风光 东风风神

